

PLxxFSA

INSTALL

Note: This is a heavy shower arm. The wall area where the arm will be installed must be reinforced to hold the shower arm.

Remove the adaptor nipple from the back of the shower arm.

Use thread sealant tape on the adaptor nipple. Do not use thread sealant compound (pipe dope). Tighten the adaptor nipple onto the elbow coming from the wall. Adaptor now needs to be flush with the finish wall.

Use an allen wrench and loosen up the set screws on the bottom of the shower flange. Carefully slide back the shower arm flange. Place the metal bracket on the back of the shower arm against the finish wall. Use a pencil to mark the hole locations on the finish wall.

Use a drill and drill in two pilot holes were the screws will be inserted.

Insert the shower arm onto the nipple adaptor. Place the bracket up against the finish wall. Use a drill and screw the wall screws to the wall. Make sure they sit firm and flush with the finish wall.

Slide the shower arm flange back against the finish wall so that it sits flush. Use the allen wrench and tighten the set screws on the bottom of the flange.